

# How to check the engine oil level

1. Take out the oil dipstick
2. Wipe off any oil residue on the dipstick using a paper towel.
3. Reinsert the dipstick back into the engine.
4. Place the motorcycle upright and on level ground, ensuring it is stable, and allow it to stand for approximately 1-3 minutes.
5. Remove the dipstick once again to check the oil level.

## How to read the oil dipstick

Adding oil is necessary when the oil level drops below the mark indicated in the picture.



Please be cautious not to exceed the maximum level indicated on the dipstick when adding oil.

